

# <WF02-5> 操作ガイド

ミッションパラメータとは、システムの動作の進捗の目安となるパラメータのことです。

**Mission Profile Definition - Regular Trip**

Overview / Management

- Regular Trip
- Mission Phases and Segments
- Mission Success Metrics
- Functional Profile
- Special Conditions
- Duty Cycles

**Mission Profile Details**

Name: Regular Trip

Duration: 1hr 18min 10sec

Σ total: 112.00 Kilometers

Mission Cycles: 1.00

Description: A short-duration trip for the vehicle assuming a benign environment and low operational loading.

**Related Documents and Images**

Documents

Images

**Mission Parameters**

Graph	Σ	Name	Units	Initial Value
<input checked="" type="checkbox"/>	<input checked="" type="radio"/>	Distance	Kilo...	0.00
<input type="checkbox"/>	<input type="radio"/>			
<input type="checkbox"/>	<input type="radio"/>			
<input type="checkbox"/>	<input type="radio"/>			
<input type="checkbox"/>	<input type="radio"/>			
<input type="checkbox"/>	<input type="radio"/>			
<input type="checkbox"/>	<input type="radio"/>			
<input type="checkbox"/>	<input type="radio"/>			
<input type="checkbox"/>	<input type="radio"/>			

**Mission Profile - Parameters Chart**

○ Distance (Kilometers)

Phase or Segment (Elapsed Time)

Phase or Segment	Elapsed Time	Distance (Kilometers)
Initial	0.00	0.00
Ignition	1.1 (0.007h)	0.00
Acceleration	2 (0.018h)	0.50
Cruise	3 (0.268h)	10.50
Turning	4 (0.285h)	11.00
Cruise2	5 (1.285h)	111.00
Deceleration	6 (1.301h)	112.00
Shut-down	7 (1.303h)	112.00